

# **MSI CRANE SCALE SAFETY AND PERIODIC MAINTENANCE MANUAL**

Safe Rigging, Loading and Operation  
Including Suggested Inspection  
and Maintenance Procedures

MODEL \_\_\_\_\_

SERIAL NUMBER \_\_\_\_\_



**Measurement Systems International**

[www.msiscalles.com](http://www.msiscalles.com)

**M S I C R A N E S C A L E**  
**S A F E T Y M A N U A L**

## Table of Contents

Forward .....	3
Safe Operating Guidelines .....	4
Operating Suggestions.....	4
Handling Hoist Motion .....	4
Safe Loading and Rigging Guidelines .....	5
Loading Procedure “Do’s” & “Don’ts” - Illustrations .....	6-8
Recommended Inspection Procedures .....	8
Load Train Visual Inspection Suggestions.....	9
Visual Inspection of Shackles.....	9
Shackle Field Inspection Areas .....	10
Shackles with Excessive Wear.....	10
Improper Replacement of Pins in Shackle .....	10
Overloaded Shackle .....	11
Shackle Eye with Twist.....	11
Scale Hook Inspection.....	11-12
Field Inspection and Repair.....	13
Recommended Preventive Maintenance.....	13-14
Notes .....	15

## Forward

This manual has been prepared to provide information and suggestions for safe operation, rigging, inspection, and maintenance of Measurement Systems International (MSI) Crane Scales.

It is not intended that the suggestions in this manual take precedence over existing plant safety rules and regulations, OSHA regulations, or instructions issued by the crane manufacturer. However, a thorough study of the following information should provide a better understanding of operation and afford a greater margin of safety for personnel and machinery.

It must be recognized that this is a manual of suggestions for the crane scale operator’s use. It is the responsibility of the owner to make personnel aware of all federal, state and local rules and codes and to make certain that operators are properly trained.

### **Safe Operating Guidelines**

Before operating a MSI crane scale, the scale operator should carefully read and study the appropriate Operation Manual supplied by MSI and note any special instructions.

### **Operating Suggestions**

1. Do not make lifts beyond rated load capacity of the crane scale, sling chains, rope slings, etc.
2. Do not operate the crane scale if ropes, slings, cables, chains, etc. show any sign of defects or excessive wear.
3. Before moving the load, make certain that load slings, load chains or other lifting devices are fully seated in the saddle of the crane scale hook with hook latch closed.
4. At no time should a load be left suspended from the crane scale unless the operator is at the master switch or push buttons with the power on; and under this condition keep the load as close to the floor as possible to minimize the possibility of an injury, should the load drop. When the crane scale is holding a load, the crane operator should remain at the master switch or push buttons.
5. When a hitcher is used, it should be the joint responsibility of the crane operator and the hitcher to see that hitches are secure and that all loose material has been removed from the load before starting a lift.
6. Do not lift loads with ropes, slings, cables, chains, etc. hanging loose.
7. All ropes, slings, cables, chains, etc. should be removed from the crane scale when not in use. (A dangling cable can inadvertently snag other objects when the crane is moving.)
8. Operators should not maneuver a loaded crane scale over personnel.

### **Handling Hoist Motion**

After the crane scale hook has been positioned over the load, lower it until the load can be attached to the scale hook. As the scale hook approaches this level, reduce the speed so that the lowering can be stopped smoothly and quickly.

If load slings are used to handle the load, the slings should be fully seated in the saddle of the scale hook. With the scale hook latch closed, the scale hook should be started upward slowly until all slack has been taken out of the slings. Then ensure the load is properly balanced and the slings are properly positioned.

### **WARNING!**

Loads may disengage from crane scale hook and shackle or lifting eye if proper procedures are not followed.

A falling load may cause serious injury or death.

The crane scale hook must always support the load. The load must never be supported by the latch.


Never lift more than the crane scale's assigned Working Load Limit (WLL) rating.

Read and understand the instructions in this manual before using the crane scale.

### **Safe Loading and Rigging Guidelines**

#### **In-line Loading**

- CAPACITY RATINGS ON THE CRANE SCALE ARE FOR IN-LINE LOADING.
- USE HARDWARE THAT CREATES SINGLE POINT ATTACHMENTS AND ALLOWS THE SCALE FREEDOM OF ALIGNMENT.



### During Loading Procedures

**DO NOT**  
USE INTERFACE HARDWARE THAT IS  
OVERSIZED. IT RESTRICTS SINGLE  
POINT LOADING AND SELF ALIGN-  
MENT AND MAY RESULT IN OFF-AXIS  
LOADING.




**DO NOT**  
PUSH OR PULL A LOADED SCALE  
AND DO NOT PULL LATERALLY ON  
THE HOOK WITH SCALE LOADED.

**DO NOT**  
SIDE LOAD, BACK LOAD OR TIP LOAD A CRANE SCALE HOOK.



## Loading the Scale Hook with Two Sling Legs.

- USE BOTTOM SHACKLE WITH HOOK FOR TWO SLING LEG LOADING.
- NEVER EXCEED 120° INCLUDED ANGLE.
- SHACKLE LOAD RATING IS BASED ON LOAD REGARDLESS OF INCLUDED ANGLE, AS LONG AS INCLUDED ANGLE IS LESS THAN 120°.



**DO NOT**  
USE MULTIPLE ATTACHMENTS WITHOUT  
THE PROPER HOOK UP OF A SHACKLE.





## Scale with Multiple Attachments

**CORRECT**

USE A SHACKLE WHEN MULTIPLE  
ATTACHMENTS ARE PLACED OVER A  
SCALE HOOK.



# MSICRANE SCALE SAFETY MANUAL



## Recommended Inspection Procedures

### Causes of Damage to Hooks, Shackles, Lifting Eyes and Load Cells

▼ CAUSE ▼	▼ RESULTANT DAMAGE ▼
Heavy use	Wear
Dragging across floors	Wear
Shock loading	Distortion
Corrosion	Reduction of structural material
Corrosion	Damage to threads
Welding	Destruction of heat treat
Overloading	Distortion
Improper use of multiple slings	Distortion
Tip loading, side loading, back loading	Distortion

### **Load Train Visual Inspection Suggestions**

- Always visually inspect scale load bearing components before using.
- Check for distortion such as bends, twists and spread.
- Inspect for wear such as peening, nicks, gouges, cracks, corrosion and thread damage.
- Magnetic Particle or Dye Penetrant crack detection of all components of the load train assembly should be conducted annually. If the crane scale hook, shackle or lifting eye are painted, visual inspection should take this coating into consideration. Surface variations can disclose evidence of heavy or severe use that requires more detailed analysis. The surface condition may, in such instances, call for stripping the paint.
- Annual inspection of the load sensor by an Authorized MSI Distributor is strongly recommended.

### **Important Safety Information**

Do not use any load bearing component that is worn beyond 5% of original dimension.


---

Remove from service any load bearing component with a detected crack.


### **Visual Inspection of Shackles**

- Check for distortion such as bends, twists and spread.
- Look for peening, nicks and gouges.
- Inspect for cracks or corrosion.
- Check for thread damage.

### Shackle Field Inspection Areas






### Shackle with Excessive Wear



### Improper Replacement of Pins in Shackle

- LOOK FOR IMPROPER REPLACEMENT OF PINS.
- NEVER REPLACE A PIN WITH A BOLT OR ANY OTHER FASTENER.







If any of the preceding conditions exist, remove shackle from service.

### **Scale Hook Inspection**

The following is a guideline to be used for the examination of scale hooks.

Common inspection methods which may be used are:  
Visual, magnetic particle and dye penetrant.



**Note:** Never use a hook whose throat opening has been increased, or whose tip has been bent more than 10° out of plane from the hook body, or is in any other way distorted or bent.

**Note:** A latch will not work properly on a hook with a bent or worn tip.

## Field Inspection and Repair

- Examine crane scale hook for excessive wear. A scale hook showing a wear-reduction greater than a 5% value should be removed from service.
- Examine crane scale hook for nicks and gouges.
- Examine crane scale hook periodically by magnetic particle and/or dye penetrant test methods, or more often in severe operating conditions. Hooks found to contain cracks should be removed from service.
- Never repair, alter, rework, or reshape any load bearing component by welding, heating, burning or bending.

## Recommended Preventive Maintenance

### Initial Inspection

Prior to use, all crane scale hook and shackle or lifting eyes should be inspected.

### Frequent and Periodic Inspection

Inspection procedures and record keeping requirements for crane scale hook shackle and lifting eyes in regular service shall be governed by the type of equipment with which they are used.

### Operator Inspection

Visual examination by the operator or other designated person; records not required.

Normal \_\_\_\_\_ Monthly

Heavy \_\_\_\_\_ Weekly

### Designated Person Inspection / Manufacturer

Visual inspections by a designated person making records of apparent external conditions to provide the basis for continuing evaluation.

Normal \_\_\_\_\_ Annual

Heavy \_\_\_\_\_ Semiannual

Severe \_\_\_\_\_ Quarterly

### Calibration

Normal \_\_\_\_\_ Annual

Heavy \_\_\_\_\_ Semiannual

### **Important Safety Information**

Repairs of cracks, nicks and gouges shall be carried out by an authorized designated person. All other repairs should be performed by the manufacturer.

---

Never repair, alter, rework or reshape any load bearing component by: welding, burning, heating or bending. Remove from service any load bearing component with wear or repair that reduces the original dimension by more than 5%.

---

### **Magnetic Particle and/or Dye Penetrant Inspection and Surface Preparation**

Inspect scale hook, shackle and lifting eye with magnetic particle and/or dye penetrant annually, or more often in severe operating conditions.

---

**Annual inspection of load sensor by an authorized MSI Distributor is strongly recommended.**

---

### **WARNING!**

Loads imposed on this product should never exceed the maximum rated capacity shown and apply only to uniform direct tension loading. Off-axis loading, bending, side loading and shock loads should be avoided. Damage caused by such, are outside of our warranty. Inspection for wear and cracks on all load bearing components should be conducted annually.

Load bearing components showing defects should be discarded. Continued use of defective components may result in catastrophic failure and personal injury.

Unless authorized by the factory in writing, changes by anyone except the factory such as cutting, welding or permanently attaching other material or products cancels all warranty.

## Notes

